




**PRODUCT INFORMATION**

**HOSE ADAPTERS**

**DESCRIPTION**

The adaptor is used to connect a hose with a 3/8" fitting to a 1/4" attachment on gas equipment (e.g. a lightweight style shank), or to connect a hose with a 1/4" fitting to a 3/8" attachment on gas equipment (e.g. a regulator outlet or a Type 3, 4 or 5 style shank).



DA6003814SLH

DA6003814BLH

**FURTHER INFORMATION**

Straight adapters are used to convert the thread size of BSP hose fittings in order to enable them to be connected to 3/8" BSP HD shank fittings.

Bent adapters are used to convert the thread size of 3/8" BSP hose fittings in order to enable them to be connected to 1/4" BSP LW shank fittings. A bent adaptor is sometimes preferred as a device for directing the gas hoses away from the shank or cutter, so as not to allow the hoses to impair movement of the equipment when welding.

The adapters are available in left hand (LH) and right hand (RH) versions for fuel and inert gas respectively.

**NOTES**

Weldability stock a complete range of gas equipment, which features many hose attachments. These attachments include hose tails (DA2001414 – DA2003856), splicers (DA30014 – DA30056), hose couplers (DA4001414LH – DA4003838RH), hose check valves (DA5001414LH – DA5003856RH) and adaptors (DA6003814BLH – DA6003814SRH).

All are manufactured to high levels of quality to help ensure a leak-proof gas line.

**ARTICLES & ACCESSORIES**

Part Number	Product Description
DA6003814BLH	BENT ADAPTOR 3/8" – 1/4" LH
DA6003814BRH	BENT ADAPTOR 3/8" – 1/4" RH
DA6003814SLH	STRAIGHT ADAPTOR 3/8" – 1/4" LH
DA6003814SRH	STRAIGHT ADAPTOR 3/8" – 1/4" RH

**TECHNICAL SPECIFICATION**

All measurements are to BSP imperial standards.

For further information, contact Weldability | Sif technical support on **0870 330 7757** or email [service@weldability-sif.com](mailto:service@weldability-sif.com)



Doc Ref: WELDABILITY/PI/DA6003814SLH